1854624
Octagonal Occasional Table-AM
Parts List

A.	Top Assembly	1 pc
B.	Stationary Shelf	1 pc
C.	Posts	4 pcs
D.	Feet	4 pcs
E.	Allen Head Bolts	8 pcs
F.	Locker Washers	8 pcs
G.	Flat Washers	8 pcs
I.	Allen Head Wrench	1 pc
J.	Optional Allen Head Screwdriver Bit	1 pc

∗ Please make sure that you have all the parts indicated above before you begin assembly of this item.
∗ This item should be assembled on a soft surface to prevent scratching the finish during assembly.
∗ This item may require periodic tightening.

Hardware Illustrations



E. Allen Head Bolt



F. Lock Washer



G. Flat Washer

1854624
Octagonal Occasional Table-AM

Assembly Instructions

1. **Attach Posts (C)** Put the Top Assembly (A) upside down on a soft surface. Align the pre-drilled holes in the Posts (C) with the pre-threaded holes in the apron blocks of Top Assembly (A). Secure, but do not tighten with Allen Head Bolts (E), Lock Washers (F) and Flat Washers (G) using Allen Head Tool (I or J). See Illustration.
2. **Attach Stationary Shelf (B) and Feet (D)** Place the finished side of Stationary Shelf (B) upside down. Insert the dowels of Posts (C) into the pre-drilled holes in the Stationary Shelf (B) so that the pre-drilled holes in Stationary Shelf (B) align with the pre-threaded holes in the bottom ends of Posts (C). Insert the exposed threads of Feet (D) through the pre-drilled holes in the Stationary Shelf (B) into the pre-threaded holes in the Posts (C) and tighten by turning in a clockwise direction.
3. **Tighten all bolts this time.**



R1-02-17-05